

### **Assembly instructions Putt Improver Indoor:**

Take the white clamping cord and thread it through the two large holes in the clamping plate

Then put the two loops on the front hole bolts.

Now clamp the white cord with the clamping plate evenly backwards. Insert the clamping plate onto the rear hole bolt. the cord should run under the plate.

Thread one loop of the orange tension cord onto the half hole bracket (top center in the notch). Slide the other loop to the white cap on the tie rod.

Insert the half hole bracket into the front hole bolts

Then insert the tension rod into the rear hole bolt

The cords should now be straight and slightly taut.

Your exercise can begin now!  
Good luck!

### **Assembly instructions Putt Improver Green (without plate):**

Take the white clamping cord and thread it through the two large holes in the clamping plate.

Thread one loop of the orange tension cord onto the half-hole bracket (centered in the notch). Slide the other loop to the white cap on the tie rod.

Lay the loops of the white tension cord with the mounted tension plate on the green. Insert the half hole bracket through the loops approx. 3-4 cm deep into the green.

Now stretch the cord evenly backwards (about 1 meter, light cord tension sufficient!). Attach the clamp with two teas to the green.

Now insert the tension rod with the attached orange cord through the middle smaller hole of the tension plate into the green.

The tension cords should now be straight and slightly tensioned.

Your exercise can begin now!  
Good luck!